

PD-300UE Series Jumper Setting

DIP SWITCH 1

SWITCH 1		Function
1	2	Interface
OFF	OFF	Virtual Com
OFF	ON	RS232 (Reserved)
ON	OFF	USB-HID
ON	ON	USB-Vendor
3		Reserved
ON		Self-test Mode
OFF		Reserved
4		Update Mode
ON		Reset ON
OFF		Reset OFF