


PD-2300 DIP Switch Setting



1. Emulation Mode:(Default:Noritake)

JP3	SW1		Mode
	1	2	
Closed	ON	ON	UTC
Closed	ON	OFF	Aedex
Closed	OFF	ON	Noritake
Closed	OFF	OFF	Epson
Opened	ON	ON	Futaba
Opened	ON	OFF	ADM

2. RS-232 Format:(Default:9600,N,8,1)

JP1	JP2	RS-232
Closed	Closed	9600,E,8,1
Closed	Opened	9600,N,8,1
Opened	Closed	19200,E,8,1
Opened	Opened	19200,N,8,1