

TX-5000/TX-5000E JUMPER SETTING

- **JCMOS1 : CMOS Select**
 - Pin 1-2 Short : Normal
 - Pin 2-3 Short : Clear CMOS
- **JP1 : COM1/COM2 12V DC SUPPLY SELECT**
 - Pin 1-3 Short : COM1 Pin1 connected to 12V
 - Pin 3-5 Short : COM1 Pin1 connected to DCD
 - Pin 2-4 Short : COM2 Pin1 connected to 12V
 - Pin 4-6 Short : COM2 Pin1 connected to DCD
- **JP2 : COM3/COM4 12V DC SUPPLY SELECT**
 - Pin 1-3 Short : COM3 Pin1 connected to 12V
 - Pin 3-5 Short : COM3 Pin1 connected to DCD
 - Pin 2-4 Short : COM4 Pin1 connected to 12V
 - Pin 4-6 Short : COM4 Pin1 connected to DCD
- **JP3 : COM5/COM6 12V DC SUPPLY SELECT**
 - Pin 1-3 Short : COM5 Pin1 connected to 12V
 - Pin 3-5 Short : COM5 Pin1 connected to DCD
 - Pin 2-4 Short : COM6 Pin1 connected to 12V
 - Pin 4-6 Short : COM6 Pin1 connected to DCD
- **JP4 : For CR open/close status port selection**
 - Pin 1-3 、 2-4 Short: For COM1
 - Pin 3-5 、 4-6 Short : For COM5
- **COM1~COM6 : +5V through BIOS ; VGA +12V through BIOS**
 - Press F2 to access Advanced/PCH-IO Configuration
 - VGA DSUB 12V : Disabled
 - COM1 DB9 5V : Disabled
 - COM2 DB9 5V : Disabled
 - COM3 DB9 5V : Disabled
 - COM4 DB9 5V : Disabled
 - COM5 DB9 5V : Disabled
 - COM6 DB9 5V : Disabled

