

## TX-2300/TX-2300E JUMPER SETTING

- **JP3 : For CR open/close status port selection**  
 Pin 1-3 、 2-4 Short: For COM1  
 Pin 3-5 、 4-6 Short : For COM5
- **JP5 : COM1/COM2 5V DC SUPPLY SELECT**  
 Pin 1-3 Short : COM1 Pin9 connected to 5V DC (By BIOS setting)  
 Pin 3-5 Short : COM1 Pin9 connected as RI  
 Pin 2-4 Short : COM2 Pin9 connected to 5V DC (By BIOS setting)  
 Pin 4-6 Short : COM2 Pin9 connected as RI
- **JP6 : COM1/COM2 12V DC SUPPLY SELECT**  
 Pin 1-3 Short : COM1 Pin1 connected to 12V  
 Pin 3-5 Short : COM1 Pin1 connected to DCD  
 Pin 2-4 Short : COM2 Pin1 connected to 12V  
 Pin 4-6 Short : COM2 Pin1 connected to DCD
- **JP7 : COM3/COM4 12V DC SUPPLY SELECT**  
 Pin 1-3 Short : COM3 Pin1 connected to 12V  
 Pin 3-5 Short : COM3 Pin1 connected to DCD  
 Pin 2-4 Short : COM4 Pin1 connected to 12V  
 Pin 4-6 Short : COM4 Pin1 connected to DCD
- **JP8 : COM3/COM4 5V DC SUPPLY SELECT**  
 Pin 1-3 Short : COM3 Pin9 connected to 5V DC (By BIOS setting)  
 Pin 3-5 Short : COM3 Pin9 connected as RI  
 Pin 2-4 Short : COM4 Pin9 connected to 5V DC (By BIOS setting)  
 Pin 4-6 Short : COM4 Pin9 connected as RI
- **JP1 : COM5/COM6 5V DC SUPPLY SELECT (TX-2300E only)**  
 Pin 1-3 Short : COM5 Pin9 connected to 5V DC (By BIOS setting)  
 Pin 3-5 Short : COM5 Pin9 connected as RI  
 Pin 2-4 Short : COM6 Pin9 connected to 5V DC (By BIOS setting)  
 Pin 4-6 Short : COM6 Pin9 connected as RI
- **JP2 : COM5/COM6 12V DC SUPPLY SELECT (TX-2300E only)**  
 Pin 1-3 Short : COM5 Pin1 connected to 12V  
 Pin 3-5 Short : COM5 Pin1 connected to DCD  
 Pin 2-4 Short : COM6 Pin1 connected to 12V  
 Pin 4-6 Short : COM6 Pin1 connected to DCD
- **CR\_PWR2 : Cash Drawer Power 12V**  
 Pin 3-4 Short : Power 12V Enable  
 Pin 3-4 Open : Power 12V Disable

- **JCMOS1 : CMOS DATA CONTROL**

DIP	Switch select	
1 & 2	1: ON, 2: ON	Clear CMOS
	1: OFF, 2: OFF	Normal Operation

- **COM1~COM4 : +5V through BIOS ; VGA +12V through BIOS**

Press ESC to access Advanced/OEM IO Configuration

VGA DSUB 12V : Disabled

COM1 DB9 5V : Disabled

COM2 DB9 5V : Disabled

COM3 DB9 5V : Disabled

COM4 DB9 5V : Disabled

COM5 DB9 5V : Disabled (TX-2300E only)

COM6 DB9 5V : Disabled (TX-2300E only)

