

XT-4015/XT-4215 JUMPER SETTING

- **JP1 : LVDS Setup**

Pin 1-3 Short 、 2-4 Short : Single LVDS & 18Bit

Pin 3-5 Short 、 4-6 Short : Dual LVDS & 24Bit

- **SEL68JP1: LVDS Input 6 Bits/8 Bits Selection**

Open : 6 Bits LVDS Input (for AUO G150XG03V3)

Short : 8 Bits LVDS Input

- **JP2 : LVDS Voltage Selection**

Pin 1-2 Short : 3.3V

Pin 2-3 Short : 5V

- **JP3 : COM3/COM4 Pin9 connected Setting**

Pin 1-3 Short : COM3 Pin9 connected to 5 V DC (By BIOS setting)

Pin 3-5 Short : COM3 Pin9 connected as RI

Pin 2-4 Short : COM4 Pin9 connected to 5 V DC (By BIOS setting)

Pin 4-6 Short : COM4 Pin9 connected as RI

- **JP4 : COM3/COM4 Pin1 connected Setting**

Pin 1-3 Short : COM3 Pin1 connected to 12V

Pin 3-5 Short : COM3 Pin1 connected to DCD

Pin 2-4 Short : COM4 Pin1 connected to 12V

Pin 4-6 Short : COM4 Pin1 connected to DCD

- **JP5 : COM1/COM2 Pin1 connected Setting**

Pin 1-3 Short : COM1 Pin1 connected to 12V

Pin 3-5 Short : COM1 Pin1 connected to DCD

Pin 2-4 Short : COM2 Pin1 connected to 12V

Pin 4-6 Short : COM2 Pin1 connected to DCD

- **JP6 : COM1/COM2 Pin9 connected Setting**

Pin 1-3 Short : COM1 Pin9 connected to 5 V DC(By BIOS setting)

Pin 3-5 Short : COM1 Pin9 connected as RI

Pin 2-4 Short : COM2 Pin9 connected to 5 V DC(By BIOS setting)

Pin 4-6 Short : COM2 Pin9 connected as RI

- **JP7 : For CR open/close status port selection**

Pin 1-3 、 2-4 Short: For COM1

Pin 3-5 、 4-6 Short : For COM5

- **JP8 : CCFL/LED Backlight Setup**

Pin 1-2 Short : CCFL Backlight Panel

Pin 2-3 Short : LED Backlight Panel

- **BLJP1 : Backlight ADJ Type Setup**

Pin 1-2 Short : For ANALOG

Pin 2-3 Short : For PWM

• **COM1~COM4 : +5V through BIOS ; VGA +12V through BIOS**

Press F2 to access Chipset\PCH-IO Configuration\

VGA DSUB 12V : Disabled

COM1 DB9 5V : Disabled

COM2 DB9 5V : Disabled

COM3 DB9 5V : Disabled

COM4 DB9 5V : Disabled

• **DIP SWITCH2 (SW2) :**

SWITCH2		FUNCTION
1 On	2 OFF	Default
1 OFF	2 ON	Clear CMOS
3	OFF	Linux or WinCE
	ON	Windows OS(Win98, Win2000, WinXP)(Default)
4	OFF	Fujitsu Touch Panel.
	ON	ELO Touch Panel or ABON Touch Panel
5	ON	Ms-DOS
	OFF	(Windows, Linux ,Win CE(Default)
6	ON	Disable On Board USB Touch (for IR Touch)
	OFF	Enable On Board USB Touch
7	ON	Raid Reset
	OFF	Raid Normal
8	ON	Reserved
	OFF	Reserved

